Schneider Electric Altivar Soft Starter ATS490 DTM Library V1.2.1

- Read Me -

This document contains important information about the Altivar Soft Starter ATS490 DTM Library software component.

Please read the complete document before you start the installation and operation of the product.

---

1. Overview

The Altivar Soft Starter ATS490 DTM Library is a software component which represents a package of Altivar Soft Starter ATS490 DTM.

Altivar Soft Starter ATS490 DTM Library Installer → **Altivar Soft Starter ATS490 DTM**

2. Altivar Soft Starter ATS490 DTM Library referenced DTM

Software Component Name	Version
Schneider Electric Altivar Soft Starter ATS490 DTM Library	V1.2.1
Altivar Soft Starter ATS490	V1.2.1.0

3. System Requirements

3.1 Supported operating systems

This software can be installed on the following operating systems:

> Microsoft Windows 10 32/64-bit

> Microsoft Windows 11 64-bit

3.2 Minimum PC Requirements

Equipment	Minimum
Processor	Pentium 4 or equivalent (Core 2 Duo, 2 GHz)
RAM	2 GB
Free Hard Disk Space	1 GB of free disk space Must be available
Display	Resolution: 1366 x 768 pixels with 32 bit colors DPI: 96(100%)

3.3 Recommended PC Requirements

Equipment	Recommended
Processor	Intel(R) Core(TM) i3
RAM	4 GB
Free Hard Disk Space	2 GB
Display	Resolution: 1920 x 1080 pixels with 32 bit colors DPI: 96(100%)

4. Software Pre Requisites

1.Microsoft.NET Framework 3.5 SP1 MUST be installed, before installing DTM Library.
This is downloadable from the Microsoft website at below link
http://download.microsoft.com/download/2/0/e/20e90413-712f-438c-988e-fdaa79a8ac3d/dotnetfx35.exe
2.Acrobrat reader DC 32 bit must be installed in the PC

5. Installation

5.1 Administrator Privileges

In order to install Altivar Soft Starter ATS490 DTM Library software component, you must have administrative privileges
to install and uninstall programs.

5.2 Re-installing or Uninstalling

You can uninstall the installer from the Add/Remove Programs Control Panel.

If you have already installed Altivar Soft Starter ATS490 DTM Library, the installer gives you options to Update,Remove
Altivar Soft Starter ATS490 DTM Library.
Note:To Repair, Altivar Soft Starter ATS490 DTM Library installer should be available.