





⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Disconnect all power from all equipment including connected devices, prior to removing any covers or doors, or installing or removing any accessories, hardware, cables, or wires except under the specific conditions specified in the appropriate hardware guide for this equipment.
 - Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
 - Replace and secure all covers, accessories, hardware, cables, and wires and confirm that a proper ground connection exists before applying power to the unit.
 - Use only the specified voltage when operating this equipment and any associated products.
- Failure to follow these instructions will result in death or serious injury.**

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel.
No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

- Use appropriate safety interlocks where personnel and/or equipment hazards exist.
- Install and operate this equipment in an enclosure appropriately rated for its intended environment.

Failure to follow these instructions will result in death or serious injury, or equipment damage.

⚠ WARNING



STRONG MAGNET!

- Can be harmful to pacemaker wearers and others with medical implants.
 - Keep tools and other metal objects away.
This magnet is strong enough to pull them out of your hand or can cause you to lose your balance and fall.
 - Keep magnetic media such as computer disks, credit cards and tapes away.
- Failure to follow these instructions will result in death or serious injury, or equipment damage.**

