SpaceLogic™ Sensors
SXWS Sensor Touchscreen Covers

Temperature Setpoint Adjustment from the Home Screen

Procedure

F-28407-1
04/2026



www.se.com

Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

Safety Information

Electrical equipment should be installed, operated, serviced and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Safety Precautions

- This product is not intended for life or safety applications.
- Do not install this product in hazardous or classified locations.
- Read and understand the instructions before installing the product.
- Turn off all power supplying equipment before working on it.
- The installer is responsible for conformance to all applicable codes.

If this product is used in a manner not specified by the manufacturer, the protection provided by the product may be impaired. No responsibility is assumed by the manufacturer for any consequences arising out of the use of this material.

© 2026 Schneider Electric All Rights Reserved.

Scope

Under standard operation, the user must navigate to the Temperature Setpoint Adjustment Screen submenu to adjust the temperature setpoint on a SpaceLogic SXWS Living Space Sensor.

It is possible, however, for the user to adjust the temperature setpoint directly from the Home screen using a workaround in EcoStruxure™ Building Operation software (EBO), as described in this document.

Note: This feature is only available in SXWS firmware version 1.15.xx and later.

Solution

Select two standard icons from the list of Available Icons on the SXWS Home screen and replace them with plus and minus (+/-) icons. When pressed, the plus and minus icons will display the Temperature Setpoint Adjustment Screen.

Implementation

To complete this workaround, follow the steps below.


1. Go to the **Display>Scene Configuration** tab in EBO and drag and drop **Icons 7 and 8** to the **Button 7 and Button 8** locations and **Save**. These particular icons and locations are rarely used and are not likely to interfere with user setup.

Figure 1. Icons 7 and 8 on the Home Screen



2. Next, go to the **Display > Properties > Button and Scene Configuration** tab to add scene buttons to the Home screen. The four button function choices can be used in any order. In this example, the buttons will be placed in the middle of the screen.

Figure 2. Selecting Buttons 7 and 8 as Front Menu Buttons



© 2026 Schneider Electric All Rights Reserved.


3. After saving this configuration, icons 7 and 8 will appear in the selected locations. Nothing happens when pressing the buttons until the feature phrase is added.

Figure 3. New Buttons on Home Screen Before Applying Feature Phrase



4. On the EBO **Display > Properties > Basic** tab, enter the feature phrase **@temp_sp** in the **Custom value text 3** field and **Save** to activate the feature.

Figure 4. Feature Phrase to Add Plus and Minus Buttons to Home Screen



5. Icons 7 and 8 displayed on the Home screen will change to plus and minus icons. Pressing either button will display the Temperature Setpoint Adjustment Screen directly. Note: The Scene menu on the device will display the same icon change and temperature adjustment shortcut.

Figure 5. Plus and Minus Buttons as a Temperature Adjustment Shortcut



To disable this feature, simply remove the feature phrase **@temp_sp** from the **Custom value text 3** field. Icons 7 and 8 will return to the Home screen, replacing the plus and minus icons. Pressing them will no longer trigger any activity within the unit.

© 2026 Schneider Electric All Rights Reserved.

Schneider Electric
35 rue Joseph Monier
92500 Rueil Malmaison – France
Phone: +33 (0) 1 41 29 70 00
www.se.com

As standards, specifications, and designs change from time to time, please ask for confirmation of the information given in this publication.

© 2026 Schneider Electric. All Rights Reserved. Schneider Electric is a trademark and the property of Schneider Electric SE, its subsidiaries and affiliated companies. All other trademarks are the property of their respective owners.

F-28407-1
04/2026