

Residual current circuit breaker with overcurrent protection (RCBO) Compliant with AS/NZS 61009.1


- PLEASE NOTE**
- The installation, maintenance and eventual replacement of this device must only be carried out by a qualified electrician.
 - This device must not be repaired.
 - All applicable local, regional and national regulations must be complied with during the installation, use, maintenance and replacement of this device.
 - This device should not be installed if, when unpacking it, you observe that it is damaged.
 - Schneider Electric cannot be held responsible in the event of noncompliance with the instructions in this document and in the documents to which it refers.
 - The service instruction must be observed throughout the life time of this device.

⚡ ⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH


- Turn off all power supplying this product before working on it.
 - Use a voltage tester with a suitable rated voltage in order to check that all active conductors aren't energized.
 - Carefully inspect the work area to check that no tools or objects could have been left inside the equipment.
- Failure to follow these instructions will result in death or serious injury.

1 Description





- A** Connection terminals
- B** Test button
- C** Clip for DIN rail mounting

2 Installation



When supply is connected to the bottom terminals, both Line & N bottom terminals will remain live even when toggle is switched off.




Top terminals	14 mm	1...16 mm²	1...10 mm²
Bottom terminals	11 mm	1...10 mm²	1...6 mm²

2 N.m	6 mm	PZ2

3

Regular test

Note: Test the device at regular intervals by pressing the Test button (marked T), following the intervals defined in your local regulations or monthly.



4

More information

