



NVE1863002

UL Type 12 kit




→ Size A

→ ATV650U07N4(E)U...U75N4(E)U
ATV650D11N4(E)U...D22N4(E)U

→ ATV950U07N4(E)U...U75N4(E)U
ATV950D11N4(E)U...D22N4(E)U

→ ATH650D22N4U



→ Size B and C

→ ATV650D30N4(E)U...D45N4(E)U
ATV650D55N4(E)U, D75N4U, D90N4U

→ ATV950D30N4(E)U...D45N4(E)U
ATV950D55N4(E)U, D75N4U, D90N4U

→ ATH650D30N4U, D37N4U, D45N4U → ATH650D55N4U, D75N4U, D90N4U

⚠ ⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Only appropriately trained persons who are familiar with and fully understand the contents of the present manual and all other pertinent product documentation and who have received all necessary training to recognize and avoid hazards involved are authorized to work on and with this equipment.
- Installation, adjustment, repair, and maintenance must be performed by qualified personnel.
- Verify compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment.
- Before performing work and/or applying voltage on the equipment, follow the instructions given in the appropriate installation manual.

Failure to follow these instructions will result in death or serious injury.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this product.

© 2026 Schneider Electric. All Rights Reserved.

